



PRECAUTIONS/SUGGESTIONS FOR USE OF FLUX AERATOR TUBE

- DO NOT HANDLE THE FLUX AERATOR TUBE WITH YOUR BARE HANDS.
Oil, grease and salts from the skin can plug the fine pores in the aerator tube. Use clean cotton or other suitable type of gloves while handling the aerator.
- ONCE THE FLUX AERATOR TUBE HAS BEEN SUBMERGED IN THE FLUX BATH IT MUST BE KEPT WET AT ALL TIMES.
Always keep the level of the flux $\frac{1}{2}$ to 1 inch over the top of the aerator when in the flux tank.

The fine pores in the aerator tube will become fluid/flux filled and if the aerator is allowed to dry the dried flux will reduce the life of the aerator tube and can make it unusable.

When not in use keep the aerator in a closed container, fully submerged in alcohol or suitable flux thinner. Never use water for storage or cleaning of the aerator.

- DO NOT OVER TIGHTEN THE HOSE FITTING/FITTINGS ON THE END/ENDS OF THE FLUX AERATOR TUBE.
Since the aerator tube is chemically resistant, the adhesive used to bond the end caps in place allows only a mechanical bond and can be broken loose with a lot of twisting force. Existing hose fittings can be reused with the new aerators.

Note: When the flux aerators no longer produce uniform, tiny bubbles of flux the aerators should be replaced.